



Name _____

- 1.1) When we first come to the pool to clean, what are the first two things we check for?
- 1.2) When connecting the vacuum hose to the vac head we connect then part of the hose that _____.
- 1.3) When priming the hose, I push it down so it is _____ with the side wall.
- 1.4) If I have primed the hose correctly, what will I see?
- 1.5) Our system runs off of _____, so it is important that there is no _____ in the hose.

- 2.1) The three main lines (valves with suction) in your pump room are:
- 2.2) In normal settings, the skimmer line should be _____ open.
- 2.3) Jandy valves are closed if they are _____ with the pipe and open if they are _____ with the pipe.
- 2.4) We never _____ all the lines if the system is on.
- 2.5) We always _____ a line before we _____ another line.
- 2.6) The _____ is connected to the pressure gauge
- 2.7) The normal setting for our multiport valve is _____.
- 2.8) In normal settings we should never see _____ moving through the site glass.
- 2.9) To be safe we should cut breaker switches on and off at the _____.
- 2.10) We know our system is primed if there is _____ in the pressure gauge and we see _____ at the top of the _____ & _____ basket

- 3.1) During the season we just need to do a _____ vac, cleaning the areas where debris is.



Name _____

3.2) When switching vacuum ports I will need to ____ - _____ the section of the hose I lay on the deck

3.3) When vacuuming through the skimmer I should take out the basket and _____ in order to fit the hose in the skimmer line.

3.4) T/F when putting the hose in the skimmer line I should put it down through the circular section on the deck surface

4.1) When vacuuming I never lift the _____ out of the water.

4.2) When finished vacuuming & I pull the hose out of the water, I watch to see the _____ go through my hose and pull it out of the port before the _____ reaches the wall.

4.3) T/F the white vacuum connector (not the cuff that swivels 360°) that connects the hose with the vacuum head should stay on the hose when I disconnect it from the vac head.

4.4) I put the vac cap back over the hole after turning off my _____.

5.1) As we vacuum up the dirt, leaves, and debris, the large items are collected in the _____ & _____ basket.

5.2) The sand in the _____ collects the smaller, fine dirt particles.

5.3) As sand collects the dirt, the _____ on the PSI gauge increases and builds up.

5.4) When backwashing I wear the _____ wristband

5.5) When backwashing it is taking the water from the pool and putting it into the _____. In essence, I am _____ the pool which is why I wear the _____ wristband.

5.6) Before backwashing I want to start at the _____ glass and follow it until it goes into the ground/wall looking for a _____ valve.

5.7) How long do we backwash for?



Name _____

5.8) When backwashing, we go from filter to _____ to _____, back to _____.

6.1) I open my hair and lint strainer basket when the system is _____.

6.2) If my system is _____ I should close my vacuum, skimmer, and main drain lines before taking off the hair and lint strainer lid.

6.3) I need to _____ my hair and lint strainer basket matching the hole in the basket with the pipe & the notch in the basket with the groove along the side.

6.4) A major thing to make sure is in place before putting the lid back on is the ____-_____. Without it the system will not prime back up.

6.5) Do not _____ - _____ the lid.

6.6) To help prime up the system I open my _____ valve on the top of the filter until _____ streams out.

7.1) If the system does not prime up naturally you have to _____ the system.

7.2) With the system off, we _____ all the valves/lines.

7.3) After this we fill up the _____ & _____ basket until water is at the top and flowing over.

7.4) After this, we put the lid on, open the main drain, and quickly _____ the system.

7.5) I also can open the _____ valve on top of the filter.

7.6) Sometimes, I can even try priming the system up on _____ instead of filter.

8.1) To acid wash, we take our screen out of the bleach barrel and place it in a bucket of _____.

8.2) We then turn our feeder to a _____ and put on our _____ wristband.



Name _____

8.3) After the bucket is empty we take the screen out and put it on the _____ while we fill our bucket with a _____ mixture.

8.4) We never _____ chemicals together.

8.5) Do we add acid to water or water to acid?

8.6) When dealing with acid washing we must wear _____ over our eyes.

8.7) After the second acid water mixture, we put the screen into a _____ bucket for the final run through.

8.8) We always do a bucket of water _____ and _____ the _____ mixture when acid washing.

8.9) Once complete we must put the screen back into the _____, and turn our feeder back to _____ setting before taking off our _____.

8.10) We acid wash in order to clean out _____ bleach from our lines and _____ fitting so that a clog does not form preventing it from entering the pool.